BLACK BULL EXHASUT NSTALLATION

CORS-AIR



ALL PARTS IN SEQUENCE

- 1. Exhaust gasket
- 2. Screws and bolts
- 3. Exhaust manifold with flex pipe
- 4. Manifold clamp
- 5. Exhaust pipe with muffler integrated
- 6. Exhaust pipe clamp
- 7. Exhaust rubber mount
- 8. Exhaust support





MANIFOLD SCREWS AND GASKET

Alternately tight the screw set until reaching 2,5 kg.



Full set assemblied and safety wire on



Clamp / rubber mount / bracket







Insert the manifold (part # 3) inside exahsut pipe (part # 5) until stopping point





- ✓ Place the manifold clamp (part # 4)
- ✓ Place the clamp next to the intersection manifold/ exhaust pipe in order to hold the assembly correctly
- ✓ Tight the clamp bolts at 1,3 kg.



As simply as this



