

Tacoma radio & clock access  
updated November 15, 2023

1. Block wheels, apply parking brake, and put gearshift into low to allow removal of center cluster finish panel.
2. Disconnect battery negative
3. Remove AM/FM radio head
4. Remove heater control knobs
5. Remove heater/AC control panel (small rectangular plate) and AC control switch (4 plastic tabs – 2@middle and 2@ends – be careful)
6. Remove (2) screws that hold center cluster finish panel. HD screw is on left, black screw on right.
7. Pry out panel w cup holder, start at top using fingernails. Detach emergency flasher switch. Lift out at bottom (2 tabs hold it). When re-installing, make sure wire bundle is down in hole so as not to interfere with cup holder. Twist bundle CW so it lies to the left.
8. If radio needs to be removed, remove radio holder, (4) bolts and unplug all wiring
9. To access clock, remove lower LH finish panel (4 bolts & 1 screw).
10. Detach hood release from finish panel (2 screws accessible from bottom of hood release lever)
11. Pry out starter switch/clock bezel and disconnect clock wiring
12. Remove clock (if the clock does not, contact us on how to fix it – you will have to have good soldering skills)